

Renaming the eBeam

You have to have the eBeam directly connected to a PC with the USB cable. It will not work on a Mac, but once you have renamed the eBeam the name will appear on any OS – Pc or Mac.

Open up the eBeam Interact Software. Go to the options icon. (It is to the right of the mouse in approximately the 5 o'clock position on the color wheel). Click on System Preferences. Then Click on Bluetooth Settings. You will see "Friendly Name." You will see that the eBeam has a 6 alphanumeric combination such as 317B22. Click Change and give it whatever name you would like. I would recommend the name of the person using it: eBeam Smith or eBeam 1st Grade, etc.

After the eBeam is renamed you can set up the Bluetooth pairing between the eBeam and as many computers as you like. When you see the eBeam device listed, it will be listed by its new friendly name that you just gave it. You can change the friendly name as many times as you like, just go through the steps above when needed.